

VZT objímka bez gumy

Informace:

Použitie

- Pre upevnenie vzduchovodov, popr. špičkového potrubia

Vhody pre Vás

- Vďaka 2 záverným skrutkám sa lepšie prispôbajú väčším toleranciam priemeru rúrky



Verze:

Symbol	Kat. číslo	Množ./bal.	Závit	Vnější Ø potrubí [mm]
M8, 50 mm	115606	1	M8	50
M8, 63 mm	115612	1	M8	63
M8, 71 mm	115618	1	M8	71
M8, 80 mm	115627	1	M8	80
M8, 90 mm	115633	1	M8	90
M8, 100 mm	115506	1	M8	100
M8, 112 mm	115512	1	M8	112
M8, 125 mm	115521	1	M8	125
M8, 140 mm	115533	1	M8	140
M8, 150 mm	115542	1	M8	150
M8, 160 mm	115548	1	M8	160
M8, 180 mm	115555	1	M8	180
M8, 200 mm	115560	1	M8	200
M8, 224 mm	115567	1	M8	224
M8, 250 mm	115576	1	M8	250
M8, 280 mm	115582	1	M8	280
M8, 300 mm	115585	1	M8	300
M8, 315 mm	115594	1	M8	315
M8, 355 mm	115600	1	M8	355
M8, 400 mm	115603	1	M8	400
M10, 450 mm	115456	1	M10	450
M10, 500 mm	115461	1	M10	500
M10, 560 mm	115464	1	M10	560
M10, 600 mm	115467	1	M10	600
M10, 630 mm	115470	1	M10	630
M10, 710 mm	115476	1	M10	710
M10, 800 mm	115479	1	M10	800