

GLSCOPDER Doplnky

Informace:

Použitie



Code/Code	Description/Description
GLSCOPDER	Observation/Plug -in point
GLSID	Adaptor selection fuse spurs (in 40) Label for use off phase selection (in 40)

Verze:

Symbol	Použití
GLSCOPDER	Plug -in point
GLSID	Štítok na oznzčenie fáz v zástrčke